

Precise Ion and Electron Beam Processing for Nano-Structuring

Regina Korntner, Hans Loeschner and Elmar Platzgummer

IMS Nanofabrication GmbH

Vienna, Austria



Outline

- Short Introduction to IMS
 - Technology Introduction
 - History of Ion and Electron Beam Structuring
 - Interaction with of Particles with Matter and Instrumentation
 - Application Overview
 - Challenges and Demands
 - Resolution
 - Productivity
- One possible solution:
- IMS Large Field Projection Optics
 - Projection Mask Less Lithography (PML2)
 - Projection Focused Ion multi-Beam (PROFIB)




Introduction to IMS



Austrian SME


„Think-Tank“
with hands-on
experience



IMS Platform Technology
for
Micro- and Nanofabrication




History of Electron Beam Structuring



**1931:
First EM
(TEM) by
Ernst Ruska**


**Nobel prize:
1986**



Principles of Ion Beam Interactions

IonShaper Simulation Program:
Elmar Platzgummer (IMS Nanofabrication),
Alfred Biedemann (TU Vienna)

Source: John Melngailis,
J.Vac.Sci.Technol.B5(2), 469, Mar/Apr 1987



EFUG 2004,
EMPA Akademie, Oct 4, 2004




IMS Nanofabrication GmbH


6

Principles of Ion Beam Interactions

Experiment: parallel FIB line scans
(Emmerich Bertagnoli, Alois Lugstein,
TU Vienna)



IonShaper Simulation Program:
Elmar Platzgummer (IMS Nanofabrication),
Alfred Biedemann (TU Vienna)





EFUG 2004,
EMPA Akademie, Oct 4, 2004



IMS Nanofabrication GmbH

7

Principles of Ion Beam Interactions



Gas Enhancement Factors:


The enhancement factor indicates the removal efficiency of the FIB process with etchant gas relative to ion sputtering without etchant

	SiO ₂	Si ₃ N ₄	Al	W	Si
XeF ₂	10	8	-	6	>100
Cl ₂	-	-	15	-	7
Br ₂	-	-	15	-	6
H ₂ O	-	-	-	-	-

Source: FIB Folder TU Berlin, Institut für Hochfrequenz und Halbleitertechnologien




Principles of Ion Beam Interactions



Courtesy: Helmut Langfischer



Principles of Instrumentation



Source: John Melngailis, University of Maryland, MNE 2003


EFUG 2004,
EMPA Akademie, Oct 4, 2004



IMS Nanofabrication GmbH

10

Technical setup of EBL tools



E-beam tool concepts

Copyright by
Raith 2004

Raith


Source: SPIE Handbook of Microlithography

Application Overview (Selection)

Typical Industrial FIB Applications

Courtesy: Zeiss NTS & RAITH

- Mask repair : defect removal & modification
- IC modification / Design edit: cut and paste operations
- SEM / TEM sample preparation: failure analysis
- Imaging & SIMS (visualizing of grain structures)
- Future: Hard disc heads



More todays Applications

- MST (prototype and development stage)
- Fabrication of scanning probe tips
- Micro Lenses and Mirrors (Aspherics)
- Nano Science and Technology !

EFUG 2004,
EMPA Akademie, Oct 4, 2004




IMS Nanofabrication GmbH

12



Nanotechnology Application: Examples

Photonic Array



Courtesy: FEI Company

QD



Courtesy: Gottfried Strasser


EFUG 2004,
EMPA Akademie, Oct 4, 2004



IMS Nanofabrication GmbH



15

Nanotechnology Application: Example



Nano Air Wires

Parallel Resistance Air-Wiring
Growth time : 2.8 min



Source: Shinji Matsui, Himeji Institute of Technology, MNE 2003

EFUG 2004,
EMPA Akademie, Oct 4, 2004



IMS Nanofabrication GmbH

16

Challenges and Demands

Talk at the MNE 2003, John Melngailis:

Nanofabrication Challenges

- milling at finer dimensions
(lower energy beams, different ion species)
- ion induced deposition at finer dimensions,
understanding deposition mechanisms
- developing novel fabrication techniques,

Source: John Melngailis,
University of Maryland, MNE 2003

Examples:

- Quantum Computing
- Nano Imprint Stamps
- Optical Components

PRODUCTIVITY


EFUG 2004,
EMPA Akademie, Oct 4, 2004




IMS Nanofabrication GmbH

17



Quantum Computing: Demands < 10nm



Courtesy: INMF Modena; Andrea Bertoni et al, Journal of Modern Optics, 2002, vol. 49, no. 8, 1219±1234




J. Gierak, Nano-fabrication with Focused Ion Beams, Poster EIBPN 2003



Courtesy: Raith




Fabrication of Nano Imprint Templates



www.smt.zeiss.com

Standard 6-inch x 6-inch x 0.250-inch fused silica blank



final template 65 x 65 mm size

www.molecularimprints.com

Template fabrication process, typically accomplished with an e-beam writer, limits the resolution of the features.





Optical Components: DOE, Fresnel Lenses

Optical Component Market Sector

Realistic market of a few \$ 100 million increasing to, perhaps \$ 300 million by 2005

Nexus Market Analysis for Microsystems, 2002

e.g.: Micro Lenses and Lens Arrays for focussing and / or redirection optical beams:
Maximise optical coupling between (laser) sources and fibre or between input and output fibres of optical switch




Yongqi Fu et al, Opt. Eng. 39(11) 3008-3013 (November 2000)



Resists - 3Dimensional Lithography



E-beam lithography and fabrication process

Gradation Curve Contrast



Introduction to IMS

IMS Platform Technology for Micro- and Nanofabrication




Large-Field Particle-Beam Optics

Ion / Electron Source

@ 200xReduction

20 μm – 1 mm



0.1 μm – 5 μm

Micro Systems Technology

SC Analytics,
Sensors, Lab-on-Chip, etc.


1 μm – 20 μm




10 – 100nm

Nanotechnology

Nanoelectronics, Nanophotonics,
BioNanoTechnology, etc.



PML2 Multi e-beam, single column




Single Electron source

Low beam energy at **Programmable Aperture Plate System (APS)**


200x reduction projection optics with 2 cross overs

Scanning Wafer Stage

PML2 Dynamic Pattern Generation



PML2 Stepwise Exposure



SPIE 2004




IMS Nanofabrication



29

Projection Focused Ion multi-Beam (PROFIB)



ion species: H^+ , He^+ , Ar^+ , Xe^+ , ...

resolution: 10nm


exposure field: $25 \mu m \times 25 \mu m$

1 million 10nm dots per second
 ($\sim 10^{16}$ ions/cm²)




Projection Focused Ion multi-Beam (PROFIB)

ims chips



Mask Plate



2 μm
mask plate
opening width

200x
reduction

10 nm
resolution, at
> 1 nA
total ion beam
current at substrate



PROFIB Target Specs


Parameter	Specification
Working Envelope	150 mm diameter; 10 mm thickness
Image Field	40 μm diameter (25 μm x 25 μm)
Resolution @ 1nA total Ar ⁺ ion beam current	10 nm
Surface roughness	< 5 nm, depending on material and feature depth
Feature Shape	adjustable shape, aspect ratio 2-3 for sputtering or 10-20 for reactive etching or deposition
Etching Rate	10 - 100 nm/s
Removal Rate	25 - 250 $\mu\text{m}^3/\text{s}$
Types of Materials	silicon, metals, ceramics, glass, compounds, ...



Projection Focused Ion multi-Beam (PROFIB)

	FIB	PROFIB	FIB compared to PROFIB @ 10nm Resolution
Ion Beam Species	Ga ⁺	H ⁺ , He ⁺ , Ar ⁺ , Xe ⁺ ,...	
Ion Beam Current Density	~ A/cm ²	~ mA/cm ²	
total Ion Beam Current at Substrate	~ pA	~ nA	higher productivity by 3 orders of magnitude

Fresnel Zone Plate
Sputtertime: 30 s
Current Density: 0,1nA/μm²



EFUG 2004,
EMPA Akademie, Oct 4, 2004



IMS Nanofabrication GmbH

33

Acknowledgements

Andrea Bertoni, University of Modena
 Albert Biedermann, Vienna University of Technology
 FEI Company
 Kleindiek Nanotechnik
 RAITH GmbH
 Gottfried Strasser, Vienna University of Technology
 Bernd Volbert, Namitec
 Carl Zeiss SMT
 Carl Zeiss NTS (former LEO)
 and IMS colleagues:
 Christoph Brandstaetter, Stefan Cernusca, Marco Kuemmel,
 Helmut Langfischer and Thomas Narzt

EFUG 2004,
EMPA Akademie, Oct 4, 2004



IMS Nanofabrication GmbH

34